


**Will - Wall  
Inredning**



## **ACOUSTIC SLAT PANEL**

— INSTALLATION INSTRUCTIONS —

2# Washed Oak  
Acoustic Slat Panel



Magnus Johnsson  
Mobil +46 (0)70 535 37 37  
magnus.ggm.johnsson@gmail.com

09. 08. 2022






## Dimension

Consists of a 9mm black or grey recycled PET Polyester acoustic fabric on which are mounted 30mm x 12mm strips in colored dark brown or black recycled MDF veneered with real wood veneer. The strips are spaced 10mm apart.

Each box contains one panels, both measuring 2750mm x 600mm. These panels will join next to each other seamlessly.

Each box covers:

- 2750mm (H)
- 600mm (W)
- 21mm (D)



## Properties of real wood veneer

Natural wood veneer can vary in color, grain structure and appearance from strip to strip and panel to panel.

## Assortment

- 2# Washed Oak
- 4# Walnut
- 5# Smoked Oak
- 6# Teak
- 8# Siner Oak
- 9# Black Oak
- 11# Black Walnut


Akustikskruv Svart  
Pcs / pk: 12  
Pcs / pk: 36  
Pcs / pk: 100  
Dimension: 5,0 x 45mm Svart / Black

## How to cut and drill

When sawing or drilling the acoustic panel, it is recommended that you first tape the area where the cut is made

should be with regular masking tape. Screw or staple the slats 50 mm inside the intended saw cut. Use a fine-toothed hand saw for veneer or a countersink/circular saw with a fine-toothed blade equipped with a guide rail for best results. Carefully sand the cut with sandpaper (fine-grained 240).

The polyester fabric of the acoustic panel is easily cut with a sharp blade.



## Care and maintenance

We recommend adding a protective finish to the panels if possible. Something like wood oil is perfect as it protects and keeps the natural look and feel of the wood. Once this is applied, light dusting or hovering will prevent any dust build-up. If you choose to keep the panels without a finish, then a dry cloth can wipe the panels down.

## How to install

There are three different options for installing

1. Gluing straight onto the wall:

A construction glue or grabadhesive is recommended for this.

2. Screwing directly into the wall:

Using black screws for the black backing option or silver or grey screws for the grey backing, the panels can be screwed directly into the wall through the acoustic felt.

We recommend a minimum of 9 screws per panel at 80mm intervals across the width and 610mm intervals down the length of the panel.

If installing into ceilings, make sure they are screwed into ceiling joists.

Please make sure the correct fixings are used if going into plasterboard, for example.

3. Screwing the panels into 45mm timber battens:

We recommend screwing 45mm timber batons to the wall and then screwing the panels directly into the batons through the acoustic felt to achieve optimum sound absorption.

Combined with Rockwool behind the panels between the batons, this will achieve Class A sound absorption.

4. As shown in the picture, install the light steel keel on the wall with a distance of 100mm from the wall, and the recommended distance between the vertical keel is 600mm, and the horizontal keel can be adjusted according to the actual situation.

The middle of the keel needs to be filled with sound insulation cotton to obtain a more perfect sound absorption effect.

The product can be fixed on the keel by screws.

## Technical Drawing

Figure 1




Figure 2



Figure 3



Figure 4

